



TRAX WALL



	<p>Class III 220-240 V~50/60Hz</p>	<p>Power 6 Watts / 12 Watts / 24 Watts / Meter</p>	<p>IP Rating IP20</p>
--	---	---	----------------------------------

CAUTION - Must Be Installed By A Licensed Electrician Only.

1. Please read the instructions for the installation of fixture provided below. Warranty will be void unless followed.
2. The installation and operation of this fixture must be in accordance with the national safety regulations. L'azure is not liable when damage is caused due to improper installation.
3. Please read the detailed product specification sheet available at www.lazurelighting.com for any technical information regarding the fixture.
4. Over-voltage protection units should be installed in order to prevent electronic and electrical components from failing due to voltage spikes.

STEP 1

LOCATION

CUT A HOLE OF 90MM IN CEILING & CHECK FOR REQUIRED DEPTH IN CEILING

STEP 2

TURN OFF THE ELECTRICITY

TURN OFF THE ELECTRICITY AT THE MAIN ELECTRICAL PANEL

STEP 3

LED DRIVER

CONNECT THE MAINS CABLE TO THE DRIVER INPUT

STEP 4

LED DRIVER

CONNECT THE FIXTURE WITH THE DRIVER USING CONNECTER

STEP 5

SIDE VIEW

ALIGN THE SPRING UPWARDS & INSTALL THE FIXTURE

STEP 6

TURN ON THE ELECTRICITY

THE FIXTURE IS INSTALLED

Disclaimer : 1. Due to continuous product improvement the installation method is subject to change.
2. Images and procedures are for representation and reference purpose only.